



There when you need us most

PC Series

Corrosion Resistant Centrifugal Pump

Installation & Operating Manual



Congratulations on Your Choice in Purchasing this Webtrol Pump!

Its Quality is unsurpassed in material and workmanship and has been factory tested.
If properly installed, it will give many years of trouble free service.

Table Of Contents

Introduction	2
Performance / Specifications	3
Exploded View & Parts List	4
Pump Inspection And Handling	5
Pre-Installation	5
Installation	5-6
Location	
Mounting	
Piping	
Electrical Connections	7-9
Start-up Procedure	10
Shaft Rotation	
Valves	
Priming	
Starting	
Final Inspection	
Trouble Shooting	11

Introduction


This manual was prepared to assist the installer and/or operator in understanding the proper method of installing, operating and maintaining the PC Series Centrifugal pump. We recommend that you thoroughly understand the proper installation and start-up procedures, prior to starting the pump. If these procedures are followed, you will have years of trouble-free service.

WARNING

Rules For Safe Installation And Operation

1. Read these rules and instructions carefully. Failure to follow them could cause serious bodily injury and/or property damage.
2. Check your local codes before installing.
3. For maximum safety, this product should be connected to a grounded circuit, equipped with a ground fault interrupter device.
4. Before installing this product, have the electrical circuit checked by an electrician to make sure it is properly grounded.
5. Before installing or servicing the pump, BE CERTAIN the pump power source is disconnected.
6. Make sure the line voltage and frequency of the electrical current supply agree with the motor wiring. If motor is dual voltage type, BE SURE it is wired correctly for your power supply.
7. Complete pump and piping system MUST be protected against below freezing temperature. Failure to do so could cause severe damage and voids the Warranty.
8. Discharge pressure not to exceed 85 PSI - suction pressure to 36 PSI - with 49 PSI boost.
9. Do not run the pump dry. If it is, there will be damage to the pump seal, and pump components.
10. Do not operate the pump in a flammable and/or explosive atmosphere.

Performance / Specifications




1/2 - 1 1/2 HP For Continuous Duty Operation


Model Number	A (Length)	HP
PC33R	9.11	1/2
PC50R	9.11	1/2
PC75R	9.86	3/4
PC100R	10.11	1
PC150R	10.31	1 1/2

Materials Of Construction	
Part	Material
Pump Housing	Noryl, GFN3 GE Thermoplastic
Motor Bracket	Noryl, GFN3 GE Thermoplastic
Impeller (closed type)	Noryl, GFN3 GE Thermoplastic
Wear Ring	316SS
Motor Shaft	303SS
Mechanical Seal	Carbon/Ceramic
O-Ring	Viton

Motor - The end-mounting motor has no feet, and is supported by the motor bracket. An open drip-proof enclosure is standard with class B insulation. Single (1) phase ODP motor dimensions for U.S. Motors motors shown.



Exploded View



Parts List

Model Number	Motor	Pump Casing	Motor Bracket	Impeller	Mechanical Seal	O-Ring	Hardware Kit
PC33R	10J05-M	20C2	12C2	15C3R	70X130-M	28C126-V	K133
PC33R-3PH	10J05-M3PH	20C2	12C2	15C3R-3PH	70X130-M	28C126-V	K133
PC50R	10J05-M	20C2	12C2	15C5R	70X130-M	28C126-V	K133
PC50R-3PH	10J05-M3PH	20C2	12C2	15C5R-3PH	70X130-M	28C126-V	K133
PC75R	10J07-M	20C2	12C2	15C7R	70X130-M	28C126-V	K133
PC75R-3PH	10J07-M3PH	20C2	12C2	15C7R-3PH	70X130-M	28C126-V	K133
PC100R	10J010-M	20C2	12C2	15C10R	70X130-M	28C126-V	K133
PC100R-3PH	10J010-M3PH	20C2	12C2	15C10R-3PH	70X130-M	28C126-V	K133
PC150R	10J015-M	20C2	12C2	15C15R	70X130-M	28C126-V	K133
PC150R-3PH	10J015-M3PH	20C2	12C2	15C15R-3PH	70X130-M	28C126-V	K133

Pump Inspection And Handling

When receiving your pump, check to see if the shipment has been damaged in any way or if any parts seem to be missing. If so, note the damage or shortage on the bill of lading and the freight bill. Make any claims to the transportation company immediately. Keep all packaging materials until the claim is resolved.

The Webtrol PC Centrifugal pump should remain in the shipping carton until it is ready to be installed.

Do not drop or mishandle the pump prior to installation.

Pre-Installation

Pump is non-submersible. Keep motor dry at all times. Do not wash or immerse the motor.

Warning: Never run the pump dry. The internal running surfaces of the pump and mechanical seal require water lubrication for consistent operation. Allowing the pump to run dry will severely damage pump and seal.

Do not pump chemicals or corrosive liquids with the pump unless they are compatible with the pump component materials. (Consult Webtrol for verification at (314) 631-9200) Use with non-flammable liquids.

To avoid internal damage to the pump, do not operate with water temperatures above 180 degrees F.

Pump must be full of liquid before operating. Do not pump dirty water or abrasive liquids. To do so, will cause the carbon seal face and elastomers in the seal to wear and leak. Mechanical seal materials, compatible with liquids containing abrasives, are available upon request.

Do not allow the pump or any system component to freeze. To do so may damage the pump and void the warranty.

Avoid air pockets in suction piping or air will accumulate at the high points making operation difficult.

Installation

Locate - The pump as close to the liquid source as possible, so that a short, direct suction pipe may be used. Place the unit so that it is readily accessible for service, maintenance and allows air to circulate freely around the motor.

Mount - Unit in a dry location, on a secure base or foundation. This will prevent noise and vibration.

Piping - Should be galvanized, rigid plastic or other suitable pipe that will not collapse when exposed to suction and discharge pressure. The piping should be as free from turns and bends as possible, as elbows and fittings greatly increase friction loss. Do not use pipe dope. Use teflon tape if needed.

Pipes must line up and not be forced into position by unions. The inlet (suction) pipe should be at least 1 1/2 inches and preferably one size larger. To reduce friction losses, the number of elbows and fittings should be kept to a minimum.

Piping should be independently supported near the pump so that no strain will be placed on the pump casing. Where any noise is objectionable, the pump should be insulated from the piping with rubber connections.

Note: Inlet pipe should be at least one size larger than suction inlet tapping. (1 1/2 NPT)

Figure 1 - Connection to a water tank which provides a gravity flow, flooded suction.




Figure 1

Figure 2 - Connection to a pressurized water system.




Figure 2

Figure 3 - The normal position of the discharge is top vertical.




Figure 3

Electrical Connections

Before wiring the pump to the power source, verify that the voltage of the motor matches the voltage of the power supply. (See Motor Nameplate) The supply voltage must be within $\pm 10\%$ of nameplate voltage.

Wire the motor according to the diagram shown on the motor nameplate. If the nameplate diagram differs from the wiring diagram shown in this manual, follow the nameplate diagram.

Install ground wire and maintain this pump in compliance with the National Electrical Code (NEC) or the Canadian Electrical Code (CEC) and with all local codes and ordinances that apply. Consult your local building inspector for local code information.


The motors used on the PC Series Centrifugal pump are manufactured by U.S. Motors, Century Electric or Baldor. Both 1 phase and 3 phase **motors are factory wired for 230 volts.**

If the supply voltage for a 1 phase motor is 115 volts refer to the wiring diagrams shown below to properly rewire the motor.


U.S. Motors 1 Phase ODP Motor		
Catalog Number	See Figure	HP
EU0502	4	1/2
EU0752	4	3/4
EU1002	4	1
EU1502	4	1-1/2*

U.S. Motors 3 Phase ODP Motor		
Catalog Number	See Figure	HP
EE155	5	1/2
EE446	5	3/4
EE506	5	1
EE607	5	1-1/2

U.S. Motors - Connection Diagrams




1 Phase, 1/2 - 1-1/2 HP
Wired 115v




1 Phase, 1/2 - 1-1/2 HP
Wired 208/230v

Figure 4

U.S. Motors - Connection Diagrams



3 Phase, 1/2 - 1-1/2 HP
Factory Wired 208/230v



3 Phase, 1/2 - 1-1/2 HP
Wired 460v

Figure 5

If the supply voltage for a 1 phase motor is 115 volts, refer to the motor wiring connections shown below to properly rewire the motor.

Century Electric 1 Phase ODP Motor		
Stock Number	See Figure	HP
T1052	6	1/2
T1072	6	3/4
T1102	6	1
T1152	6	1-1/2

Century Electric 3 Phase ODP Motor		
Stock Number	See Figure	HP
T3052	7	1/2
T3072	7	3/4
T3102	7	1
T3152	7	1-1/2

Century Electric Motors - Connection Diagrams




Figure 6

Century Electric Motors - Connection Diagrams




Figure 7

If the supply voltage is 460 volts, refer to the motor wiring diagram show in (Figure 5) to properly rewire the motor.


Motor shaft rotation - 3 phase motors

1. Turn the power off.
2. Remove the circular end cap located on the back of the motor. This will expose the motor shaft.
3. Momentarily start pump. If the connection is correct, the shaft will rotate clockwise. If not reverse any two incoming lines (Power Leads).


Baldor 1 Phase ODP Motor		
Catalog Number	See Figure	HP
JL1303A	8	1/2
JL1306A	8	3/4
JL1309A	8	1
JL1313A	8	1 1/2

Baldor 3 Phase ODP Motor		
Catalog Number	See Figure	HP
JM3107	12	1/2
JM3111	12	3/4
JM3115	12	1
JM3120	12	1 1/2

Baldor Motors - Connection Diagrams




1 Phase, 1/2 - 1-1/2 HP
Wired 115v




1 Phase, 1/2 - 1-1/2 HP
Wired 230v

Figure 8

Baldor Motors - Connection Diagrams



3 Phase, 1/2 - 1-1/2 HP
Factory Wired 230v



3 Phase, 1/2 - 1-1/2 HP
Wired 460v

Figure 9

Start-Up Procedures

Shaft Rotation - To check for a free turning pump turn the power off and rotate the motor shaft. This can be done by removing the motor end cap located on the back of the motor. Rotate the motor shaft in a clockwise direction. Do not start the pump if the motor shaft cannot be turned.

Shaft Rotation (3 Phase Motors) - After the proceeding instructions have been completed, turn the motor on for **1 second**. If the connection is correct, the motor shaft will rotate clockwise when viewed from the end opposite the motor shaft extension. If the rotation is not correct, reverse any two leads to the starter. The rotation will now be correct.

Valves - The suction inlet valve should be fully open and the discharge valve should be partially open. This will allow the pump to develop back pressure when it is started.

Priming - The pump will automatically fill with water when the pump is connected to a city main, hydrant or water tank. To relieve the air trapped inside the pump, allow the water supply to run a minimum of 1 minute before starting the pump. Then, turn the motor on and off several times to free the air trapped inside the pump. Repeat this priming sequence several times to be sure all the air has been removed from the pump. Start and run the pump for 1 minute. The pump should be pumping water and rapidly build pressure. If not repeat the priming procedure.

Warning: The pressure gauge installed in the inlet line should never read less than 2 PSI. This insures that an ample supply of water is flowing into the pump.

Starting - When the pump is up to operating speed, open the discharge valve to obtain the desired capacity or pressure. Do not allow the pump to run with the discharge valve closed because the liquid in the pump can get extremely hot.

Warning: The discharge pressure should never be allowed to exceed 85 PSI, otherwise, leakage between the motor bracket and pump casing will occur.

Final Inspection - Once the proceeding instructions have been completed the pump can be started. During the first few hours of operation, inspect the pump, piping and auxiliary equipment used in conjunction with the pump. Check for leaks, vibration or noises.

If a problem arises, consult a Webtrol representative or call Webtrol at (314) 631-9200 for assistance.

Maintenance

The pump does not require special maintenance. If the pump is not going to be used for a long period, the pump should be drained of water and flushed with clean water. Where the pump is exposed to freezing temperatures, it should always be left drained when not in use.

System Trouble Shooting

Motor Fails To Start Or Run At Full Speed

Possible Cause Of Trouble	Corrective Action
Start capacitor failed - 1 phase motor (motor hums)	Replace start capacitor
Power Loss	Replace bad fuse or reset circuit breaker (check for correct fuse/breaker size)
Incorrect voltage - voltage must be within $\pm 10\%$ of motor rated voltage. Example: Rated voltage 230 volts Range: 207 - 253 volts	1. Check incoming voltage, contact power company 2. Verify that the voltage of the motor matches the power supply voltage 3. Check wire size from main switch to motor.
Defective wire or connections	Replace defective wires, tighten and clean connections.
Grounded motor	Have motor rewound with new winding or replace motor.
Wired for incorrect voltage	Check motor wiring diagram for proper voltage

Pump Leaks

Possible Cause Of Trouble	Corrective Action
Worn mechanical seal due to abrasive liquid/corrosion	1. Replace seal with materials compatible with liquid pumped. 2. Install filter on inlet line.
Lack of water - carbon seal on mechanical seal face overheats and cracks or wears rapidly	1. Replace seal 2. Verify inlet pressure, minimum pressure on inlet gauge is 2 PSIG
Inlet pressure too high	1. Discharge pressure not to exceed 85 PSI 2. Reduce inlet pressure
Misalignment of mechanical seal	Check for a bent motor shaft
Worn or pinched O-ring seal	Replace O-ring seal

Pump Operates, But Delivers Little Or No Water

Possible Cause Of Trouble	Corrective Action
Incorrect rotation on 3 phase motor	Interchange any two incoming power leads to the motor.
Low line voltage	(See motor trouble shooting section above)
Air Locked Pump	Fill pump & inlet pipe with water - jog motor on and off several times. Refill with water. Repeat procedure several times to remove all air
Worn or plugged impeller	1. Replace impeller 2. Clean clogged impeller, install filter on Inlet
Inadequate inlet pressure	Minimum pressure on the inlet side of pump is 2 PSIG
Diameter of suction/discharge pipe is too small	1. Size of inlet pipe should be at least equal to the threaded inlet size in the pipe inlet housing 2. Calculate friction losses for the discharge pipe. Replace undersized piping. For assistance call Webtrol (314) 631-9200
Broken Shaft	If motor shaft is broken replace motor
Wired for incorrect voltage	Check motor wiring diagram for proper voltage

Excessive Noise While Pump Is Operating

Possible Cause Of Trouble	Corrective Action
Cavitation (noise like gravel in pump)	1. Increase size of inlet line 2. Reduce flow rate - GPM 3. Too viscous (liquid is too thick) maximum viscosity is 80 centipoise (CPS)
Pump not secured to firm foundation	Bolt down to secure and rigid base
Noisy motor	1. Ensure that motor fan is clear 2. Remove motor from pump. If noise persists check for smooth bearing operation. Replace bad bearings/or motor
Wired for incorrect voltage	Check motor wiring diagram for proper voltage

